

Mazda RX7 Rotary

52	IGNITION 4 O/P	RED/WHT
51	IGNITION 3 O/P	YEL/BLK
49	IGNITION 2 O/P	PNK/BLK
48	IGNITION 1 O/P	PNK/WHT
47	IGNITION 0/P	BLK
46	IGNITION 0/P GND	BLK
45	IGNITION 0/P GND	BLK
44	IGNITION 0/P GND	BLK
43	ANTI LAG SW	
42	SWITCH 2 I/P (BOOST CURVE SEL)	PNK/YEL
41	SWITCH 1 I/P (A/C REQUEST/T.C. ENABLE)	GRY
40	VEHICLE SPEED I/P	BRN
39	SPARE SPEED I/P (TURBO TACH)	GRN
38	CYL PULSE TRIGGER I/P	YEL
37	REF. TRIGGER I/P	GRN
36	TRIGGER GND	BLK
35	TRIGGER SUPPLY	RED/BLK
34	AUX 3 ANALOG I/P GND	
33	AUX 3 ANALOG I/P	
32	AUX 1 ANALOG I/P	
31	AUX 4 ANALOG I/P	
30	AUX 2 ANALOG I/P	
29		
28	THROTTLE POSN SUPPLY	RED
27	THROTTLE POSN GND	BLK
26	THROTTLE POSN I/P	ORG
25	AIR INTAKE GND	
24	AIR INTAKE TEMP I/P	WHT
23	EBP I/P	GRY/BLU
22		
21	O2/EGT I/P	
20	COOLANT TEMP GND	
19	COOLANT TEMP I/P	PNK
18	ANALOG O/P	BLU
17	SOL 3 O/P (SPARE)	BLU
16	IGNITION SW I/P	PUR
15	PWM 2 O/P (BOOST)	PNK/YEL
14	INJECTOR 1 O/P	RED/WHT
13	PWM 1 O/P (IDLE)	PNK
12	INJECTOR 2 O/P	ORG/BLK
11		
10	ECU GND	BLK
9	INJECTOR 3 O/P	BLU/WHT
8	INJECTOR 4 O/P	GRN/WHT
7	INJECTOR 5 O/P	GRN/YEL
6	INJECTOR 6 O/P	BLU/BLK
5	INJECTOR 7 O/P	YEL/BLK
4	ECU +12V SUPPLY	RED
3	INJECTOR 8 O/P	BLU/RED
2	ECU +12V SUPPLY	RED
1		

